


HD Video Conferencing Camera



User Manual

V1.0

(English)

Preface

Thanks for using this HD Video Conferencing Camera.

This manual introduces the function, installation and operation of the HD camera. Prior to installation and usage, please read the manual thoroughly.

Precautions

This product can only be used in the specified conditions in order to avoid any damage to the camera:

- Don't subject the camera to rain or moisture.
- Don't remove the cover. Otherwise, you may get an electric shock. In case of abnormal operation, contact the authorized engineer.
- Never operating under unspecified temperature , humidity and power supply;
- Please use the soft dry cloth to clean the camera. If the camera is very dirty, clean it with diluted neuter detergent; do not use any type of solvents, which may damages the surface.

Note

This is class A production. Electromagnetic radiation at the specific frequency may affect the image quality of TV in home environment.

Contents

Note.....	1
Supplied Accessories	3
Quick Start	4
Features.....	7
Product Specification	8
Main Unit.....	10
IR Remote Controller Explanation	11
USE IR Remote Controller	13
RS-232 Interface	17
VISCA Network Configuration	18
Serial Communication Control	19
VISCA Network Configuration	20
Menu Setting.....	21
Equipment Setup and internet connection (Only network version)	27
IP camera visited/ controlled by LAN	27
IP Camera accessed/controlled by WAN (internet).....	29
IP Camera parameter setup	31
Maintenance and Troubleshooting	37

Note

- **Electric Safety**


Installation and operation must accord with electric safety standard.

- **Caution to transport**

Avoid stress, vibration and soakage in transport, storage and installation.

- **Polarity of power supply**

The power supply of the product is +12V, the max electrical current is 2A .Polarity of the power supply plug drawing as follows.



- **Careful of installation**

Do not grasp the camera head when carrying the camera. Don't turn camera head by hand. Doing so may result in mechanical damage.

Don't apply in corrosive liquid, gas or solid environment to avoid damaging the cover which is made up of plastic material.

To make sure no obstacle in rotation range.

Never power on before installation is not completed.

- **Don't dismantle the camera**

We are not responsible for any unauthorized modification or dismantling.

CAUTION!

The specific frequency of electromagnetic field may affect the image of the camera!


Supplied Accessories

When you unpack, check that all the supplied accessories are included:

Camera	1PCS
AC power adaptor	1PCS
Power cord	1PCS
RS232 cable	1PCS
Remote controller.....	1PCS
User manual	1PCS

Quick Start

Step1. Please check connections are correct before starting



Step2. Setting of the system select switch

The option of video format:

VIDEO SYSTEM			
0	-	8	-
1	-	9	-
2		A	-
3		B	-
4	720p60	C	-
5	720p50	D	576i
6		E	480i
7		F	

CAUTION:

- a. After changing the switch, you need to restart the camera to take effect.

Step3. Press the Switch ON/OFF button on the rear of the camera, the power lamp light.

Step4. Pan-Tilt will rotate to the maximum position of top right after the camera started, then it return to the center, the process of initialization is finished. (Note: If the position preset 0 has been stored, the position preset 0 will be called up after initialization)

Step5. (Optional) If you want to restore the factory default settings, Press [MENU] button to display the OSD menu. Select the item [MENU] -> [RESTORE DEFAULT] -> [Restore]. Set the value [Yes], press [HOME] button to restore the factory default settings.

RESTORE DEFAULT

▶Restore Yes

◀▶ Change Value

[Home] OK

[Menu] Back

Features


1. Adopt Panasonic's 1/2.7 inch, 1.3 million pixels high quality HD CMOS sensor, which can achieve maximum 1280 x 720 high resolution and quality image with highest output frame rate 60 FPS.
2. High SNR of CMOS sensor combined with 2D and 3D noise reduction algorithm, effectively reduce the noise, even under low illumination conditions, picture can still keep clean and clear.
3. Support HD-SDI interface, effective transmission distance up to 100 meters. Supports SD CVBS output.
4. Use TAMRON high quality super telephoto lens, support 20x optical zoom, and 16x digital zoom.
5. Using RS232/485 interface, all the parameters of the camera can be remote controlled by the high-speed communications.
6. Support multi-channel of audio and video streams output.

Product Specification

Name	HD Video Conferencing Camera
Camera	
Video System	720p/60,720p/50,NTSC PAL
Sensor	1/2.7", CMOS, Total Pixel: 1.44M, Effective Pixel: 1.31M
Scanning Mode	Progressive
Lens	20x, f5.5mm ~ 110mm, F1.6 ~ F3.5
Digital Zoom	16x
Minimal Illumination	0.5 Lux @ (F1.8, AGC ON)
Shutter	1/25s ~ 1/10000s
White Balance	Auto, Indoor, Outdoor, One-Push, Manual
Backlight Compensation	Support
Digital Noise Reduction	2D&3D Digital Noise Reduction
Video S/N	≥55dB
Horizontal Angle of View	50.5° ~ 2.7°
Vertical Angle of View	29.7° ~ 1.5°
Horizontal Rotation Range	±170°
Vertical Rotation Range	-30° ~ +90°
Pan Speed Range	1.7° ~ 100°/s
Tilt Speed Range	1.7° ~ 69.9°/s
Horizontal flip & Mirror	Support
Number of Preset	245
Preset Accuracy	0.1°
Input/Output Interface	
HD Output	1xHD-SDI: BNC Type, 800mVp-p, 75Ω, Along to SMPTE 292M standard

SD Output	1xCVBS: RCA jack, 1Vp-p, 75Ω
Network interface	1xRJ45: 10M/100M Adaptive Ethernet ports
USB Interface	1xUSB2.0: A type jack
Communication Interface	1xRS-232 IN: 8pin Min DIN, Max Distance: 30m, Protocol: VISCA/Pelco-D/Pelco-P
	1xRS-232 OUT: 8pin Min DIN, Max Distance: 30m, Protocol: VISCA/Pelco-D/Pelco-P
	1xRS-485: 2pin cellular port, Max Distance: 1500m, Protocol: VISCA/Pelco-D/Pelco-P
Power jack	JEITA type (DC IN 12V)
Generic Specification	
Input Voltage	12V DC (10.8 ~ 13.0V DC)
Current Consumption	2.0A (Max)
Operating Temperature	-5°C ~ 40°C
Storage Temperature	-20°C ~ 60°C
Power Consumption	12W
Size	142mm x 169mm x 176mm
Weight	1.5Kg

Main Unit



1. CVBS Interface

2. System select switch

3. RS485 jack

4. RS232 IN jack

5. RS232 OUT jack

6. Network


7. HD-SDI Interface

8. USB2.0

9. DC 12V jack

10. Power switch

IR Remote Controller Explanation



0. Standby Button

Press this button to enter standby mode. Press it again to enter normal mode.

(Note: Power consumption in standby mode is approximately half of the normal mode)

1. Position Buttons

To set preset or call preset

2. * Button

3. Set/Clear Preset Buttons

Set preset: Store a preset position

[SET PRESET] + Numeric button (0-9): Setting a corresponding numeric key preset position

Clear preset: Erase a preset position

[CLEAR PRESET] + Numeric button (0-9)

Or: [*]+[#]+[CLEAR PRESET]: Erase all the preset individually

4. BLC (Backlight Compensation) Button

BLC ON/OFF: Press this button to enable the backlight compensation. Press it again to disable the backlight compensation. (NOTE: Effective only in auto exposure mode)

Note: If a light behind the subject, the subject will

become dark. In this case, press the backlight ON / OFF button. To cancel this function, press the backlight ON / OFF button.

5. Focus Buttons

Used for focus adjustment.

Press [AUTO] adjust the focuses on the center of the object automatically. To adjust the focus manually, press the [MANUAL] button, and adjust it with [Focus +] (Focus on far object) and [Focus -] (Focus on near object)

6. Camera Select Buttons

Press the button corresponding to the camera you want to operate with the remote controller.

7. # Button

8. Pan/Tilt Control Buttons

Press arrow buttons to perform panning and tilting. Press [HOME] button to face the camera back to front

9. Menu Setting

Menu button: Press this button to enter or exit the OSD menu

10. Zoom Buttons

Zoom▲: Zoom In

Zoom▼: Zoom Out

11. Set Camera IR Address Buttons

[*]+[#]+[F1]: Address1

[*]+[#]+[F2]: Address2

[*]+[#]+[F3]: Address3

[*]+[#]+[F4]: Address4

USE IR Remote Controller


When the camera is working, you can use remote controller to perform panning, tilting, zooming and focusing, store and call back preset positions.

Button Instruction:

1. In this instruction, 'press the button' means the press and relax the two actions. Such as 'press [HOME] button' means to press the [HOME] key and then relax action, and a special note will be given if a hold down for more than one second is required.

2. When a button-combination is required, do it in sequence. For example, '[*] + [#] + [F1]' means press [*] first and then press [#] and press [F1] at last.

1. Pan/Tilt Control



Move up: Press [▲]

Move down: Press [▼]


Move left: Press [◀]

Move right: Press [▶]

Face the camera back to front: Press [HOME]

Press and hold the up/down/left/right button, the camera will keep rotating from slow to fast, until it run to the mechanical limit; the camera stops as soon as the button is released.

2. Zoom




Zoom Out: press [ZOOM▼] button

Zoom In: press [ZOOM▲] button

Press and hold the button, the camera will keep zooming in or zooming out and it stops as soon as the button is released.

3. Focus Control



Focus Far: Press [FOCUS+] button (NOTE: Effective only in manual focus mode)


Focus Near: Press [FOCUS-] button (NOTE: Effective only in manual focus mode)

Press and hold the button, the action of focus continues and stops as soon as the button is released.

AUTO: Change focus mode to AF, adjusting the focus automatically.

MANUAL: Change focus mode to MF, adjusting the focus manually.


4. Backlight Switch



BLC ON/OFF: Press this button to enable the backlight compensation. Press it again to disable the

backlight compensation. (Note: Backlight is only effective in full auto exposure mode)

5. Presets Set/Clear



1. To store a preset position: The users should press the [SET PRESET] button first and then press the numeric button 0-9.


10 preset positions in total are available.

2. To erase the memory content of a preset position: The users should press the [CLEAR PRESET] button first and then press the numeric button 0-9.

Note:

Press [*]+[#]+[CLEAR PRESET] will erase all preset individually positions in the memory.

6. Recalling the Preset




Press any of the numeric buttons 0-9 directly to recall stored preset positions and settings.

Note:

No action is executed if a relative preset position is not stored.

7. Camera Selection



Press the button corresponding to the camera you want to operate.

8. Camera IR Address Set




[*]+[#]+[F1]: Address1

[*]+[#]+[F2]: Address2



[*]+[#]+[F3]: Address3

[*]+[#]+[F4]: Address4


RS-232 Interface



No.	Function
1	DTR
2	DSR
3	TXD
4	GND
5	RXD
6	GND
7	IR OUT
8	NC



VISCA Network Configuration



Serial Communication Control

In default working mode, the camera is able to connect to a VISCA controller with RS232C serial interface.

➤ **RS232 Communication Control**

The camera can be controlled via RS232 ,the parameters of RS232C are as follows:

Baud rate: 2400/4800/9600 bit/s.

Start bit: 1 bit.

Data bit: 8 bits.

Stop bit: 1bit.

Parity bit: none.

➤ **RS485 Communication Control**

The camera can be controlled via RS485, Half-duplex mode, supports VISCA or Pelco-D or Pelco-P protocol, supports the following configurations:

Baud rate: 2400/4800/9600 bit/s.

Start bit: 1 bit.

Data bit: 8 bits.

Stop bit: 1bit.

Parity bit: none.

Pan-Tilt will rotate to the maximum position of top right after the camera started, then it return to the center, the process of initialization is finished. (Note: If the position preset 0 has been stored, the position preset 0 will be called up after initialization) Then the users can control the camera with commands in the command list.

VISCA Network Configuration

Ignore


Note:

VISCA Command List, Please contact the manufacturer.

Menu Setting


1. MENU

Press [MENU] button to display the main menu on the normal screen, using arrow button to move the cursor to the item to be set. Press the [HOME] button to enter the corresponding sub-menu.



2. EXPOSURE

Move the cursor to the Exposure item in the main menu and press [home] button, EXPOSURE menu appears, as shown in the following figure.



Mode: Exposure mode. Optional items: Auto, Manual, SAE, AAE, Bright

ExpCompMode: Exposure compensation mode, Optional items: On, Off (Effective only in Auto mode)

ExpComp: Exposure compensation value, Optional items: -7 ~ 7 (Effective only in ExpComp Mode item to On)

Gain Limit: Maximum gain limit. Optional items: 0 ~ 15 (Effective only in Auto, AAE, Bright

mode)

Backlight: Set the backlight compensation,
 Optional items: On, Off (Effective only in Auto
 mode)

DRC:DRC strength, Optional items: 0 ~ 8.

Bright: Intensity control, Optional items:00~17.
 (Effective only in Bright mode)

Anti-Flicker Flicker: Anti-flicker. Optional
 items: Off, 50Hz, 60Hz (Effective only in Auto,
 Bright mode)

Iris: Aperture value. Optional items: F1.8,
 F2.0,F2.4,F2.8,F3.4,F4.0,F4.8,F5.6,F6.8,F8.0,F9.6,F
 11.0,Close(Effective only in Manual, AAE mode)

Shutt.: Shutter value. Optional items: 1/30,1/60,
 1/90,1/100,1/125,1/180,1/250,1/350,1/500,1/725,1/1
 000,1/1500,1/2000,1/3000,1/4000,1/6000,1/10000
 (Effective only in Manual, SAE mode)

3. COLOR

Move the cursor to the Color item in the main
 menu and press [home] button, COLOR menu
 appears, as shown in the following figure.

COLOR	
▶ WB Mode	Auto
RG Tuning	0
BG Tuning	0
Saturation	90%
Hue	7
AWB sens	Low
▲▼ Select Item	
◀▶ Change Value	
[Menu] Back	

WB-Mode: White balance mode. Optional
 items: Auto, Indoor, Outdoor, One Push(ok),Manual

RG: Red gain. Optional items: 0~255(Effective
 only in Manual mode)

BG: Blue gain. Optional items:
 0~255(Effective only in Manual mode)

RG Tuning: Red gain fine-tuning, Optional
 items: -10~10(Effective only in Auto, Indoor,
 Outdoor mode)

BG Tuning: Blue gain fine-tuning, Optional
 items: -10~10(Effective only in Auto, Indoor,

Outdoor mode)

Sat: Saturation. Optional items: 60% ~ 200%.

Hue: Chroma adjustment, Optional items: 0 ~ 14

AWB sens: The white balance sensitivity, Optional items: Normal, High, Low.

Style: Optional items: Style 1, Style2, Style3.

4. IMAGE

Move the cursor to the Image item in the main menu and press [home] button, IMAGE menu appears, as shown in the following figure.

IMAGE	
► Luminance	6
Contrast	6
Sharpness	1
Flip-H	Off
Flip-V	Off
B&W-Mode	Off
Gamma	Default
SD Ratio	16:9
▲▼ Select Item	
◀▶ Change Value	

Luminance: Brightness adjustment. Optional items: 0 ~ 14

Contrast: Contrast adjustment. Optional items: 0 ~ 14

Sharpness: Sharpness adjustment. Optional items: Auto, 0 ~ 15

Flip-H: Image flipped horizontally. Optional items: On, Off


Flip-V: Image Flip Vertical. Optional items: On, Off

B&W-Mode: Image color. Optional items: On, Off

Gamma: Optional items: Default, 0.45, 0.5, 0.56, 0.63

SD Ratio: Optional items: 16:9, 4:3.

5. P/T/Z




SpeedByZoom: The depth of field scale switch,
Optional items: On, Off

AF-Zone: Interested in focusing area, Optional
items: Top, Center, Bottom

AF-Sense: Automatic focusing sensitivity
options, Optional items: Low, Normal, High

6. NOISE REDUCTION

Move the cursor to the Noise Reduction item in
the main menu and press [home] button, NOISE
REDUCTION menu appears, as shown in the
following figure.



NR2D-Level: 2D noise reduction. Optional
items: Off, Auto, 1 ~ 5

NR3D-Level: 3D noise reduction. Optional
items: Off, 1 ~ 8

D-HotPixel: Dynamic bad points, Optional
items: Off, 1 ~ 5

7. SETUP

Move the cursor to the Setup item in the main menu and press [home] button, SETUP menu appears, as shown in the following figure.

SETUP	
► Language	EN
Protocol	VISCA
V_Address	1
V_AddrFix	Off
Net Mode	Serial
Baudrate	9600
▲▼ Select Item ◀▶ Change Value [Menu] Back	

Language: menu language, Optional items: EN, Chinese

Protocol: Control protocol type. Optional items: AUTO, VISCA, PELCO-D, PELCO-P

V_Address: Protocol address, To be decided according to the agreement, AUTO, VISCA protocol
Optional items: 1 ~ 7

P_D_Address: PELCO-D protocol Optional items: 0 ~ 254

P_P_Address: PELCO-P protocol Optional items: 0 ~ 31

V_AddrFix: If I can change through the serial port of infrared switch, Optional items: On, Off(When set to On, useless in 88 30 01 FF Command)

Net Mode: Set the serial port control networking, Optional items: Serial, Paral

Baudrate: Serial port baud rate. Optional items: 2400, 4800, 9600

8. RESTORE DEFAULT

Move the cursor to the Restore Default item in the main menu and press [home] button, RESTORE DEFAULT menu appears, as shown in the following figure.

RESTORE DEFAULT

►Restore? No

◄► Change Value

[Home] OK

[Menu] Back

Restore: Confirm restore factory settings.
Optional items: Yes, No

Note: Press [HOME] button to confirm, All
parameter restore default, Include IR Remote
address and VISICA Address

Save: Save Options. Optional items: Yes, No

Equipment Setup and internet connection (Only network version)

Operating Environment

Operating System: Windows 2000/2003/XP/vista/7/8

Network Protocol: TCP/IP


Client PC: P4/128MRAM/40GHD/ support scaled graphics card, support DirectX8.0 or more advanced version.

1. Equipment Installation


- 1) Connect internet camera to your internet or to your PC directly via internet cable.
- 2) Turn on DC12V power.
- 3) The orange light of internet port lit on, green light flashing, and the physical connection finished.

2. Internet Connection

Connection ways between internet camera and computer, as picture 1.1 and picture 1.2 shown:



Picture 1.1 connect by internet cable



Picture 1.2 Connect by router /interchanger

IP camera visited/ controlled by LAN

1. Setup IP address

IP camera default IP address "192.168.100.88",
Unknow camera IP, view as below:

Method 1: press * and # and 4 on remote controller one by one, the camera IP address will be shown on screen.

Method 2: connect camera to PC with ethernet cable, use "upgrade_En.exe" to search for IP address



Change IP address, 2 methods as below:

Method 1: On web control page, find "Network"--->Change IP---->Click "Apply"----->Restart camera

Lan Settings

IP Configuration Type: Fixed IP Address

IP Address: 192.168.100.88

Subnet Mask: 255.255.255.0

Gateway: 192.168.100.1

DNS Address: 192.168.100.1

MAC Address: D4 : E0 : 8E : DB : 18 : 06

Port Settings

HTTP Port number: 80 (80)

RTSP Port: 554 (554)

PTZ Port: 5678 (5678)

Control Protocol Settings

Visca Address: 1 (1~7)

Pelco-D Address: 0 (0~255)

Pelco-P Address: 0 (0~31)

RTMP Settings

First stream: ☐ On ☐ Off ☐ Video ☐ Audio

MRL: rtmp://192.168.100.138/live/stream0

Second stream: ☐ On ☐ Off ☐ Video ☐ Audio

MRL: rtmp://192.168.100.138/live/stream1

ONVIFSetting

ONVIF: ☐ On ☐ Off

Multicast Settings

Multicast: ☐ On ☐ Off

Address: 224.1.2.3

Port: 6688

Apply Cancel

UPGRADE v1.8 Simple

upgrade search config backup

Mode: Manual

IP Address: 192.168.100.88

Mask: 255.255.255.0

GateWay: 192.168.100.1

First DNS: 192.168.100.1

MAC Address: D4 : E0 : 8E : 9E : C3 : B0

Set Reset



NOTE!

IP camera default IP address "192.168.100.88", user "admin", password "admin".

2. Visit/Access IP Camera

Input http://192.168.100.88 to IE (better with IE web browser, others will cause little latency), a login window pop up, input login name: admin, password: admin, shown as below:

Method 2: Open "upgrade_En.exe", change IP and click "Set". After modified, IP Camera be restart.



After login, shown as below:



NOTE!

If user first time use this camera by internet (only for new user), must install a player software (VLC). Please go to VLC webside <http://www.videolan.org/vlc/download> and Install VLC (player software). After installation, login again,will show as above:

IP Camera accessed/controlled

by WAN (internet)

1. Setup IPC accessed/controlled by dynamic DNS

2 dynamic DNS available:

Dyndns.org,

3322.org

Router Port Mapping:

Take TP-LINK router for example, enter Router Home Page (interface page),select “Transit control”- “Transit rule”--“Virtual server”-- “Virtual service” ,add a new port number in “Outside Port” ,add a new port number in “inside port”, put camera IP address to “IP address”, then select “Apply” and “Add”, shown as below: (sorry, we do not have English Version TP-Link here, so put the Chinese Version picture for reference, the position is the same)

虚拟服务			
服务名称:	2		
Outside Port:	外部端口:	554	- 554
Inside Port:	内部端口:	554	- 554
服务协议:	TCP/UDP		
内部服务器IP:	192.168.1.90		
启用/禁用规则:	<input checked="" type="radio"/> 启用 <input type="radio"/> 禁用		
Add <input type="button" value="新增"/> <input type="button" value="清除"/> <input type="button" value="帮助"/>			

虚拟服务

服务名称:

3

新增

外部端口:

89 - 89

清除

内部端口:

80 - 80

帮助

服务协议:

TCP/UDP

内部服务器IP:

192.168.1.90

启用/禁用规则:

☒ 启用 ☐ 禁用

服务列表

选择	序号	服务名称	服务协议	外部端口	内部端口	内部服务器IP	状态	设置
<input type="checkbox"/>	1	2	TCP/UDP	554	554	192.168.1.90	已启用	
<input type="checkbox"/>	2	1	TCP/UDP	88	80	192.168.1.89	已启用	
<input type="checkbox"/>	3	3	TCP/UDP	89	80	192.168.1.90	已启用	

2. Dynamic DNS visit camera

Set domain name to camera, setup the parameter, then dynamic DNS can access camera. Access link: <http://hostname:port> number For example, setup host computer name: youdomain.f3322.org, camera port number: 554, Access link should be: <http://youdomain.3322.org:554>.




If camera port default as 80, then unnecessary to input port number, use host name can access camera directly .

3. VLC stream media player monitoring

Visit VLC media server procedure

Open VLC media player, click "Media"->"Open Network Steam", or click "Ctrl+N"; as below:




Input URL address:

rtsp://ip: port number/1 (Main stream);

rtsp://ip: port number/2 (Sub stream).



RTSP port number default 554.



IP Camera parameter setup

1 Homepage introduction

Menu

All pages include 2 menu bars:

Real time monitoring: displaying video image

Parameter setup: with function buttons


1.1 Video viewing window

Video viewing window must be same as video resolution, the bigger the resolution is, the bigger the playing area is. Double click viewing window, will show full-screen, double click again, will return to initialized size.

Status bar in viewing window shown as below

- 1) Video playback pause button: control real-time video pause, stop the last picture, click recoverable video again.
- 2) Audio control buttons: can set silent mode.
- 3) Full screen switch button.

1.2 PTZ Setup



- 1) PTZ direction control box: Up, down,

left, right, home oblique button as above

2) Rate: Vertical speed can be chosen as 1 ~ 24, horizontal direction at the rate of 1 ~ 20.

3) select corresponding speed and click direction button to realize PTZ speed up or speed down.

4) Zoom In/Zoom out: for zooming in or zooming out, Focus In/ Focus Out: Focusing on distant objects or Focusing on close objects.

5) Set/Call: When PTZ turn to expected position, can set up a number of preset that user want. click "Set" button,when PTZ turn to other position, click "Call" button,PTZ turn back to preset position.


1.3 Language selection

中文 English

Chinese/English

2 Media

1) Video Setup,please click "Video"



The image shows a 'Video settings' window with a blue background. It contains two sections: 'First stream' and 'Second stream'. Each section has settings for Resolution, Bit rate, Maximum frame rate, I key frame interval, Bit rate control, and Fuctuate level. At the bottom right are 'Apply' and 'Cancel' buttons.

Section	Resolution	Bit rate	Maximum frame rate	I key frame interval	Bit rate control	Fuctuate level
First stream	1920x1080	4096 kbps (32-8192)	25 fps	25 (2-150)	<input checked="" type="radio"/> CBR <input type="radio"/> VBR	1
Second stream	320x240	1024 kbps (32-6144)	25 fps	25 (2-150)	<input type="radio"/> CBR <input checked="" type="radio"/> VBR	1

2) Video format

Support 50HZ(PAL)and 60HZ(NTSC), and Dial priority three formats.

3) Video Coding

Support baseline and mainprofile format

4) Resolution

Main bit flow support 1920x1080, 1280x720,minor bit flow support 640x360, 320x180,the bigger resolution is, the clearer the

image will be, more network bandwidth will be taken.

5) Bit Rate

User can assign bit flow/stream, normally speaking, the bigger bit flow is, the clearer the image will be. The bit allocation must combine with network bandwidth, when the network bandwidth is too narrow and the allocated bit flow is too big, will cause video signal flow not to be transmitted normally, the video effect will be worse.

6) Maximum frame rate

User can specify the size of the frame rate, generally, the frame rate greater, the image more smooth; Frame rate is smaller, the more sense of beating.

7) Bit Rate control

Code stream control way:

Constant bit rate: video coder will be coding according to preset speed

Variable bit rate: video coder will adjust the speed based on preset speed to gain the best image quality.

8) I key frame interval:


Set interval between 2 I frame, the bigger interval is, the response will be lower from viewing

window.

9) dFluctuate level

Restrain the fluctuation magnitude of variable rate, grade 1 ~ 6

3 Image Setup, please click “Image”



1) Brightness

Image bright 0~100, slider control, on the right shows the corresponding numerical. Default 43.

2) Saturation

Saturation 0~100, slider control, on the right shows the corresponding numerical. Default 50.

3) Contrast

Contrast 0~100, slider control, on the right shows the corresponding numerical. Default 57.

4) Sharpness

Sharpness 0~100, slider control, on the right shows the corresponding numerical. Default 16.

5) Hue

Hue 0~100, slider control, on the right shows the corresponding numerical. Default 50.

6) Distortion

Adjusted the wide-angle lens image distortion occurs, controllable range 0 ~ 100, right shows the corresponding numerical. Default 0.


7) Flip & Mirror

Tick Flip to realize image upside down, tick mirror to realize image around the mirror. Default not tick.

8) Button

Adjusting the parameters, press "apply" button to save, press "cancel" button to cancel the adjustment of the parameters, press "default" button obtain the default value.

4 Audio Setup, please click "Audio"



Audio Settings

Audio Type: AAC ▾

Sample Rate: 48K ▾

Bit Rate: 96K ▾

Input Type: Line in ▾

Input Vol L : 0 (-97~30) db

Input Vol R : 0 (-97~30) db

Apply Cancel

1) Audio Type

Audio type AAC

2) Sample rate

Sample rate 44.1 K and 48 K, selectable.

3) Bit rate

Bit rate 96k, 128k, 256k, selectable

4) Input Type

line in only

5) Input VolL

The volume of the left channel


6) Input VolR

The volume of the right channel

7) Button

Press "apply" button to save parameters, press "cancel" button to cancel parameter

5 System Setting, please click “System”



1) Work Mode

Work Mode RTSP

2) Reboot

Click the "Reboot" button, system restart.

3) User and password

The user can modify the password (letters and Numbers only)

4) Apply / Cancel

Modify password and click the "apply" button to the login page, press "cancel" button to cancel password change.

6 Network Setting, please click “Network”



1) Lan Settings

Default the IP address is 192.168.100.88, The MAC address can be modified.

2) Port Settings

IP address identifies the network device, the device can run multiple web applications, each network program using network port to transmit data, so data transmission to be carried out between the port and port. Port setting is to set up WEB SERVER program using which port to transmit. When port mapping, need to be consistent with the port number(default port: 80)

3) RTSP Port

Network camera support RTSP protocol, use the VLC tools broadcast.

4) TCP Port


Support TCP protocol, default port: 5678.

5) Apply / Cancel

Modify network parameters then press "Apply" button to modify network parameters, press "Cancel" button to cancel network parameters.

7 Device Information, please click “information”

Show the current device information, as shown below.



The screenshot shows a blue dialog box titled "Information" in red text. It contains three rows of information, each with a label on the left and a text field on the right. The first row is "Device ID:" with the value "HD Camera". The second row is "Software Version:" with the value "SOC v3.1.64 - ARM v4.1.66S". The third row is "Webware Version:" with the value "v1.2.7". At the bottom right of the dialog box are two buttons: "Apply" and "Cancel".

Label	Value
Device ID:	HD Camera
Software Version:	SOC v3.1.64 - ARM v4.1.66S
Webware Version:	v1.2.7

Maintenance and Troubleshooting

Camera Maintains

- If camera will not be used for a long time, please turn off the power switch, disconnect AC power cord of AC adaptor to the outlet.
- Use soft cloth or tissue to clean the camera cover.
- Please use the soft dry cloth to clean the lens. If the camera is very dirty, clean it with diluted neuter detergent. Do not use any type of solvents, which may damages the surface.

Unqualified Application

- No shooting extreme bright object for a long period of time, such as sunlight, light sources, etc.
- No operating in unstable lighting conditions, otherwise image will be flickering.
- No operating close to powerful electromagnetic radiation, such as TV or radio transmitters, etc.

Troubleshooting

Image

- No image
 1. Check whether the power cord is connected, voltage is OK, POWER lamp is light.
 2. Check whether the camera can self-test after startup.
 3. Check the BOTTOM switch and make sure the two switches are both set OFF.
 4. Check video cable is connected correctly.
- Image dithering even at widest zoom position
 1. Check whether camera is fixed correctly.
 2. Make sure if there are something like vibration machine or other things nearby.
- IE browser not video image IE

When IPC first time accessed by Internet Explore (IE or other web browser), must install plug-in.

User first time use this camera by internet (only for new user), must install a player software (VLC). Please go to VLC website <http://www.videolan.org/vlc/download> and Install VLC (player software). After installation, login again, will show image, the video image is displayed.

- Unable to access IP Camera by IE browser.
 1. Access to the network with PC can test whether network works, in this way to get rid of cable failure, network failure caused by PC virus until the PC can be Ping.
 2. Disconnect IP Camera with network, IP Camera and PC are connected, according to the proper operations to re-set the IP address.
 3. Check the server's IP address and subnet mask and gateway address.
 4. MAC addresses conflict.
 5. Web port is occupied by other devices.
- When modify IP address in an incorrect way cause the wrong IP address or forget web passwords, press the IR remote controller "[*]+[#]+[Manual]" to restore the default value (Default IP: 192.168.100.88 Default username: admin Default password: admin)

Control

- IR remote controller cannot control the camera
 1. Change the battery
 2. Check the camera working mode.
 3. Check IR address of the Remote Commander is set correctly.
- Serial communication cannot control the camera
 1. Check the camera working mode.
 2. Check control cable is connected correctly.

Copyright Notice

All contents of this manual, whose copyright belongs to our Corporation. Cannot be cloned, copied or translated without the permission of the company. Product specifications and information which were referred to in this document are for reference only, and the content will be updated at any time without prior notice.

2015/3